



## Supported Devices/Поддерживаемые устройства

### L Series

- **L7**
    - BSL39601
  - **L9**
    - BSL41601
- 

### S19 Series

- **S19**
    - NBS1902
  - **S19 88 / 84 / 126**
    - BHB42801, BHB42803, BHB42811, BHB42821, BHB42831, BHB42841
  - **S19i**
    - NBS2003
  - **S19a**
    - BHB28611
  - **S19a Pro**
    - BHB28501
  - **S19 Pro**
    - BHB42641, BHB42651
  - **S19 Pro-A**
    - NBP1901
  - **S19j Pro**
    - BHB42601, BHB42603, BHB42621, BHB42631, BHB42632
  - **S19j Pro+**
    - BHB42611, BHB42612
  - **S19j+**
    - BHB42701
  - **S19j XP**
    - BHB56804, BHB56807
  - **S19 XP**
    - BHB56601, BHB56801, BHB56802, BHB56806
  - **S19k Pro**
    - BHB56901, BHB56902, BHB56903, TS007
- 

### T19 Series

- **T19**
  - NBT1903

---

## S19 Hydro Series

- **S19 Hydro**
  - HHB28601
- **S19 Pro Hyd.**
  - HHB42602
- **S19 Pro+ Hyd.**
  - HHB42601, HHB42631
- **S19XP Hyd.**
  - HHB56601, HHB56611, HHB56613
- **S19 XP+ Hyd.**
  - HHB68701, HHB68703, HHB68704
- **S19e XP Hyd.**
  - H6HB56702

---

## T19 Hydro Series

- **T19 Hydro**
  - HHB28602
- **T19 Pro Hyd.**
  - HHB56701, HHB56702

---

## S21 Series

- **S21**
  - BHB68601, BHB68603, BHB68606
- **S21 Pro**
  - A3HB70601, A3HB70602, A3HB70603
- **S21 XP**
  - A3HB70501, A3HB70502, A3HB70503
- **S21+**
  - A3HB70701, A3HB70702

---

## S21 Hydro Series

- **S21 Hyd.**
  - HHB68501, HHB68502, HHB68503, HHB68504, HHB68601, HHB68602
- **S21+ Hyd.**
  - H6HB70701, H6HB70702, H6HB70704
- **S21e Hyd.**
  - H6HB70801, H6HB70802
- **S21 XP Hyd.**

- H6HB70501
  - **S21 XP Hyd. / S21 Pro Hyd.**
    - H6HB70601, U3S21EXPH, H1HB70601
- 

## **Immersion**

- **S21 Immersion**
  - IHB68601
- **S21XP Immersion**
  - M1HB70602